




A reference is included with the rack that provides measurements and specifications for your car.

SportRack FRONTIER Ref.		30 Adapter Adaptador 30 A21116		Front Avant Frente		Rear Arrière Atrás		Weight Limit Limite de poids Limite del peso		Fit Tips Conseils d'installation Consejos del ajuste	
Vehicle Make and Model Marque et Modèle du véhicule El vehículo Marca y Modelo	Year Année Año	Front Fronte	Rear Arrière	A		B		Lbs	Kg		
<b>ACURA</b>											
EL 4DR	01-06	14	16	11	270	24 3/4	629	130	59	4	
EL 4DR	07-09	9	9	8 1/4	210	27 1/2	699	130	59		
TDX 4DR	08-11	27	24	11 3/4	298	20 3/4	527	105	48		
<b>CHEVROLET</b>											
Impala 4DR	08-11	27	22	9	203	20	500	105	48	4	

## IF YOUR CAR IS NOT ON THE LIST, DO NOT INSTALL THE RACK.

Check: [https://cdn.shprtn.com/media/mfg/572/media\\_document/7975/SRGuide\\_short.pdf](https://cdn.shprtn.com/media/mfg/572/media_document/7975/SRGuide_short.pdf)

Contact: CargoGear: 866-792-6614 Thule (SportRack): 800-238-2388




You need to turn really hard with the little wrench to get 53 inch pounds

With the 3 inch long wrench included you will need to apply:  
 $(53 \text{ in lbs}) / (3 \text{ in}) = 17.6 \text{ lbs force}$  applied at the very end of the wrench.  
 In the middle of the handle, or evenly distributed over the handle of the wrench you would need twice that force.

Tighten screw **X** to 6Nm / 53 in-lbs.

It is crucial that the pads rest as flush as possible on the roof of the car.



The pads can rotate very stiffly. You can put the rack upside-down on a bench or table, and grab the pad with two hands to get things going.

### Check the install:

Grab the rack securely and push, pull, up, down, forward, backward.  
 Give it a workout. The rack should be solid on the car,  
 and the car should rock on its suspension.